

Instructions for wear checks of play equipment

The equipment must be checked for correct operation and safety, especially the points listed below:

Proof of maintenance

Playground.....

Date of installation

Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.


Intervals for maintenance work and checks generally depend on

- the location
- the usage
- the frequency of use
- possible vandalism

For more details see also "General instructions for maintenance of playgrounds".

Slackline

Order No. 7.15500/7.15600



Wooden parts

1. Check for rot and, if necessary, smooth out splinters and round off sharp edges of cracks.
2. **Recommendation:** apply paraffin wax to the upper end grain areas once a year, please refer to order No. 0.90100, 1 litre.

Belt

3. Ensure that the slackline is securely connected by checking the belt slings; retighten if necessary.
4. Check belt strap for wear and tear; it must be replaced if there are any cut marks, fraying or similar damage.

Additional information

Do not use any chemicals, soap or detergent for cleaning.

When storing the slackline textiles, store in dry and well ventilated rooms. Protect from heat, chemicals, soiling and mechanical damage. Please pay attention to the depicted care symbols.



Special notes, e.g. for repairs

Repair not carried out, it is still possible to play on equipment

Repair not carried out, equipment is taken out of action

All work carried out, everything is in order

Maintenance carried out by:

..... Date

Instructions for wear checks of play equipment

The equipment must be checked for correct operation and safety, especially the points listed below:

Proof of maintenance

Playground.....

Date of installation

Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.



Intervals for maintenance work and checks generally depend on

- the location
- the usage
- the frequency of use
- possible vandalism

For more details see also "General instructions for maintenance of playgrounds".

Slackline

Order No. 7.15500/7.15600



Ratchet

5. Check tensioning lever, sprockets, shackles and release for cracks and deformation (see detailed diagram).
6. Check that the interlock mechanism and slotted shaft run smoothly and, if required, lubricate the contact points (see detailed diagram).

Additional information:

Belt straps, hoses and iron parts must not be used any longer if one of the following instances occurs:

- yarn breaks or cuts into the fabric deeper than 10 % of the cross-section
- damage to the load-bearing seams
- deformation as the result of the effects of heat, such as friction
- knots in the line as a connection between lines or shackles or as tree harness
- damage caused by the effects of aggressive substances
- deformation, hairline fissures, breaks, widening by more than 5%, significant corrosion or other damage to tensioning or connecting elements such as: deformation of the slotted shaft, release bent, tensioning lever broken or cracked, sprockets worn, shackles deformed or broken

Structural stability

7. Uncover the foundation once a year in order to check for rot or, in the case of posts made of steel, for corrosion.

Special notes, e.g. for repairs

Repair not carried out, it is still possible to play on equipment

Repair not carried out, equipment is taken out of action

All work carried out, everything is in order

Maintenance carried out by:

..... Date