Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:		Proof of maintenance		
Playground		Wooden parts			
Date of installation	1.	Check for rot and, if necessary, smooth out splinters and round off sharp edges of cracks.			
Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static	2.	Check that all bolts and screws are tight and retighten if necessary.			
equipment at least once a year. Intervals for maintenance work and checks	3.	Recommendation: apply paraffin wax to the upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre.			
generally depend on <ul> <li>location</li> <li>kind of use</li> </ul>	4.	Check the ash wood rungs of the ladder for wear and tear, the remaining diameter must be at least 30 mm.			
<ul> <li>frequency of use</li> <li>possible vandalism</li> </ul>		Inclined Climbing Net			
For more details see also "General instructions for maintenance of	5.	Check that connection points are tight and retighten if necessary.			
playgrounds".	6.	Check the climbing net for wear and tear, if the steel reinforcement is damaged it is imperative it be replaced.			
Platform House Order No. 4.14914		Slide			
	7.	Check the slide surface for vandalism.			
	8.	Check that all screws and bolts are tight, retighten if necessary.			
		Crane			
	9.	Check all functional parts and retighten screws and bolts, if necessary. Check bearings/chains for wear and tear.			
		Structural stability		pairs	
10	10	In order to check for rot at wooden parts or steel feet for corrosion, uncover the foundation once a year.		, e.g. for re	
	11.	Net: check the connection (tensioning hook) to the anchoring chain, if necessary re-tension the net at the bottom ends.		Special notes, e.g. for repairs	
	Repair not carried out, it is still possible to play on equipmentRepair not carried out, equipment is taken out of actionAll work carried out, everything is in order				
	Ма	aintenance carried out by:			
For spare parts refer to back of page.	Date				

En-EN 23.09.2015

COPYRIGHT © RICHTER SPIELGERÄTE GMBH

Spare Parts Platform House Order No. 4.14914



Please note that the safety standards of the equipment must not be affected. Therefore, when carrying out repairs it is helpful to **only use original parts.** 

Order No.	Spare part	
0.97150	Crane fitting complete	