Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance
Playground Date of installation	Mechanics 1. Check rocking function	
Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year. Intervals for maintenance work and checks generally depend on - location - usage - frequency of use - possible vandalism For more details see also our general instructions for maintenance of playgrounds! EVOPÄD Indoor Rocker Order No. 12.00100 EVOPÄD Outdoor Rocker Order No. 12.00110	<ul> <li>Wooden parts</li> <li>If necessary, smooth out splinters.</li> <li>Check that all bolts and screws are tight and retighten if necessary.</li> <li>If necessary, treat the surface (oil).</li> </ul>	Special notes, e.g. for repairs
	Repair not carried out, it is still possible to play on equipment	
	Repair not carried out, equipment is taken out of action	
	All work carried out, everything is in order	
	Maintenance carried out by:	