		_
Instructions for wear checks of play equipment	The equipment must be checked for correct operation and safety, especially the points listed below:	Proof of maintenance
Playground	Wooden parts	
Date of installation	 Check for rot and, if necessary, smooth out splinters and round off sharp edges of 	
Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.	cracks.2. Check that all bolts and screws are tight and retighten if necessary.	
Intervals for maintenance work and checks generally depend on	3. Recommendation : apply paraffin wax to the upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre.	
- location	Ctructural stability	
- usage - frequency of use	Structural stability	
- possible vandalism	 In order to check steel feet for corrosion, uncover the foundations once a year. 	
For more details see also our general instructions for maintenance of playgrounds!		
Fastening Frame for attachment of Bridges to Square Tower Order No. 3.66350		Special notes, e.g. for repairs
	Repair not carried out,	
~ (7)	it is still possible to play on equipment	
	Repair not carried out, equipment is taken out of action	
	All work carried out, everything is in order	
	Maintenance carried out by:	<u> </u>
	Date	