

**General hints:**

**A. Surfacing requirements**

This equipment should be installed on an impact absorbing surfacing / loose fill material that accords with EN 1177 and is adequate for a maximum free height of fall of 1.50 m.

**B. Foundations**

Please see detailed instructions at the end of this document, especially depths of foundations for steel feet.


**Special information:**

Tested by TÜV Product Service GmbH.

Please do not alter any parts of the equipment or the construction itself since this may affect the safety standards and your guarantee.

We reserve the right to make technical alterations!  
For further information please call your local agent.

**Wobbly Platform**  
Order no. 8.81500



**Data for shipment:**

Number of parts: 2


- 1 Wobbly Platform with 3 guy ropes
- 1 steel foot

Total weight: 300 kg  
Heaviest single part: 270 kg

**Required space including safety distances (EN 1176):**

Ø 5.60 m

**Ground elevation**  
Scale 1:50  
all dimensions in cm



**Foundation blocks**

Quality of concrete C 25/30

3 pieces 80 x 80 x 40 cm  
Excavation depth 100 cm

1 piece 100 x 100 x 60 cm  
Excavation depth 100 cm


**Recommended assembly tools:**


- Set of carpenter's tools
- Set of ratchets
- Set of spanners
- Rubber mallet
- Torx inserts T 20, 25, 30, 40, 50

**Attention!**



During the assembly period (including the setting of the concrete) it is not allowed to play on or put any weight on the equipment in order to secure stability during use after the assembly. Standard concrete requires at least 2 weeks to set.

**Sequence of assembly operations:**

1. Locate the site and take into account the space required, including the safety distances, according to the ground elevation on page 1.
2. Start surveying at the point of reference  and dig out the foundation holes.




3. Place the steel foot of the Wobbly Platform into the central foundation and align exactly vertically.
4. Fill the foundation holes with concrete and tamp.  
**Please take into account the special sheet: Notes on the construction of foundations.**
5. Detach guy ropes from the guy anchors and place them into the damp concrete according to **Detail A**.




6. After the concrete has set, put Wobbly Platform onto the steel foot and align exactly vertically. The Platform's floor must be exactly horizontally.
7. Re-attach the guy ropes to the guy anchors (if necessary shorten the chain). Tauten turnbuckles till the system is slightly and equally pre-loaded. See **Detail B**.
8. Following, move the Wobbly Platform to all sides. If there is an end stop audible in the steel foot, increase the tension of the guy ropes. Repeat procedure if necessary.

**Note:** The number of the handrail ties depends on the number of attached equipment. This sketch exemplary shows a Wobbly Platform with 3 handrail ties.



9. Cover the foundations up to ground level with surfacing material.
10. Repair minor damages caused during assembly or transportation.
11. Please ensure that all assembly aids, e. g. excess bolts, assembly instructions, distance battens or tape are removed entirely from the play equipment and the playground after work is finished.

**Detail B**



**Please note that after about 6 weeks all screws and bolts need to be checked and, if necessary, retightened.**

