

**General hints:**

**A. Surfacing requirements**

according with EN 1177  
no special requirements

**B. Foundations**

Please see detailed instructions  
at the end of this document.

**Special information:**

Tested by TÜV Product Service GmbH.


Please do not alter any parts of the equipment or  
the construction itself since this may affect the safety  
standards and your guarantee.

We reserve the right to make technical alterations!  
For further information please call your local agent.

**Phones in wood**

1 pair

**Order no. 9.02700**



**Model for nurseries**

**Order no. 9.02720**

**Data for shipment:**

Number of parts: 3

2 phones

1 bundle plastic pipe

Total weight: 150 kg  
Largest single part: 65 kg  
36 x 38 x 150cm  
or 36 x 38 x 110 cm

**Ground elevation**

Scale 1:100


all dimensions in cm

**Foundation blocks**

2 pieces 60 x 60 x 40 cm

Excavation depth 60 cm

Ditch for pipe max. 17 m long



**Recommended assembly aids:**



- Set of carpenter's tools
- Set of ratchets
- Torx insert T 20, 25, 30, 40, 50
- Rubber mallet
- Spirit level

**Attention!**


During the assembly period (including the setting of the concrete) it is not allowed to play on or put any weight on the equipment in order to secure stability during use after the assembly. Standard concrete requires at least 2 weeks to set.

**Sequence of assembly operations:**


1. Locate the site and take into account the space required according to the ground elevation on page 1. The distance between the Phones is approx. 15 m, it must not exceed 17 m.
2. Dig out the foundation holes and the ditch for the pipe.
3. Lay the pipes on a bed of sand, approx 10 cm thick.
4. Remove the cover from the back of each Phone.
5. Place the Phones into the foundation holes. Cut the vertical pipes to length until they reach to the bottom of the foundation holes. Push a pipe sleeve onto one end and connect using a 90° pipe bend.
6. Refill the ditch with the excavated material.



7. Check both Phones with the spirit level and align vertically if necessary.
8. Fill the foundation holes with concrete B 25 (earth damp), largest grain size 16 mm and tamp. Round the edges of the foundations and cover with ground material.




9. Install the covers to the back of the Phones.



10. Repair minor damages caused during assembly or transportation.

11. Please ensure that all assembly aids, e. g. excess bolts, assembly instructions, distance battens or tape are removed entirely from the play equipment and the playground after work is finished.



**Please note that after about 6 weeks all screws and bolts need to be checked and, if necessary, retightened.**